

B R Y D G E 12.3

USER MANUAL

FOR MICROSOFT SURFACE® PRO 3 & 4



Have a question? Contact Brydge directly at
support@brydgekeyboards.com


B R Y D G E 12.3

1 SHIMS

IMPORTANT:

Your Brydge 12.3™ is set up for the Surface® Pro 4

If you have a Surface Pro 3, you will need to replace the shims in the keyboard with those in the box



TO REPLACE: Remove the current shims, and ensure the surface is smooth

NOTE: Removing all remaining glue is not essential



Remove tape backing from front and back of new shims and insert evenly into hinges




NOTE: Ensure the shim is pressed firmly against the bottom of the hinge before pressing on the front and back

6 STORAGE (Brydge 12.3 Pro 128 only)


- 1) Connect the included USB 3.0, one end to the Surface (USB - Type A), and the other end to the keyboard (Micro B)

2) Brydge 12.3 Pro 128 appears as an external drive in your file explorer

3) Use as you would any other external hard drive



2 INSERT/REMOVE




Place your Brydge on a flat surface, insert your Surface into the hinges with the kickstand at the bottom (and closed)

Lift your Surface to test the hinge grip. Your Surface and Brydge should be held firmly together



If the Surface is loose, remove and give the hinges a gentle squeeze. Repeat this process until your Surface is held firmly



To remove, hold your Surface and pull straight up, with one hand firmly holding your Brydge against a hard surface

3 POWER



To manually power on, press and hold Fn + Delete keys
The light will turn green for 3 seconds to indicate power



To manually power off, press and hold Fn + Delete keys for 3 seconds
The light will turn red momentarily to indicate it's powered off

NOTE: Once paired, your Brydge will automatically wake upon opening the Surface. The Delete key will turn green for three seconds to let you know your Brydge is awake

NOTE: To conserve battery, your Brydge will enter sleep mode after 20 minutes of non-use. Press any key to turn back on. Your Brydge will enter sleep mode when both devices are closed like a laptop

4 PAIR



To pair, press and hold the Bluetooth key for three seconds.
The Delete key light will flash blue confirming your Brydge is in pairing mode

NOTE: If pairing takes longer than one minute, the blue light will stop flashing and you will need to press the Bluetooth button again


- 1) Select Windows icon (start menu)
- 2) Select 'Settings'
- 3) Select 'Devices'
- 4) Select 'Bluetooth'
- 5) Confirm Bluetooth is on
- 6) Select 'Brydge 12.3', then 'pair'
- 7) Enter the on-screen passcode and press enter

5 CHARGE



To check battery life, press the battery key. The Delete key will flash three times:

Green = 75-100%
Yellow = 25-74%
Red = 10-24%



Insert the supplied Micro USB cable



Charging is confirmed by a solid red light on the Delete key. Your Brydge is fully charged when the light turns off

NOTE: Charging can take up to 3 hours

KEYBOARD SHORTCUTS

Help

F1

Start

Ctrl + Esc

Task View

Alt + Tab

Undo

Ctrl + Z

Cut

Ctrl + X

Copy

Ctrl + C

Paste

Ctrl + V

Underline

Ctrl + U

Italic

Ctrl + I

Page Up

Fn + Up Arrow

Page Down

Fn + Down Arrow

Home

Fn + Left Arrow

End

Fn + Right Arrow

Language Switch

Win + Spacebar

(Spacebar allows you to toggle through available languages)

Touchpad Disable/Enable

Fn + Alt

Hold Fn and tap Alt to disable

Hold Fn and tap Alt again to enable

Switch to Windows 8

Fn + W + 8

(LED Turns Green)

Scroll Direction

Fn + T

(Scroll Up: LED turns blue)

(Scroll Down: LED turns green)

Switch to Windows 10

Fn + W + 0

(LED Turns Blue)

Function Key Swap

Fn + Caps

(F1 - F12 Swap)

TRACKPAD FUNCTIONALITY

- Left click on left side of trackpad

- Right click on right side of trackpad

NOTE: Any motion or click on the trackpad will wake up your Brydge from sleep mode



Expand



Open Apps



Desktop



Cortana®

PAIR

To pair, press and hold the Bluetooth key for three seconds.
The Delete key light will flash blue confirming your Brydge is in pairing mode

NOTE: If pairing takes longer than one minute, the blue light will stop

flashing and you will need to press the Bluetooth button again


CHARGE



To check battery life, press the battery key. The Delete key will flash three times:

Green = 75-100%
Yellow = 25-74%
Red = 10-24%

B R Y D G E | 2.3



Find more information at www.brydgekeyboards.com

© 2017 Brydge. All Rights Reserved.
Surface®, Microsoft®, Windows®, and Cortana® are registered trademarks of Microsoft Corporation. The Bluetooth word, mark, and logos are owned by Bluetooth SIG, Inc. Use of such marks by Brydge is under license. Brydge is a trademark of Brydge Global Pte. Ltd. Other trademarks and tradenames are those of their respective owners.